



Gowin_EMPU_M1

Serial Debugging Reference Guide

IPUG535-1.2E,08/18/2019

Copyright©2019 Guangdong Gowin Semiconductor Corporation. All Rights Reserved.

No part of this document may be reproduced or transmitted in any form or by any denotes, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of GOWINSEMI.

Disclaimer

GOWINSEMI[®], LittleBee[®], Arora[™], and the GOWINSEMI logos are trademarks of GOWINSEMI and are registered in China, the U.S. Patent and Trademark Office, and other countries. All other words and logos identified as trademarks or service marks are the property of their respective holders, as described at www.gowinsemi.com. GOWINSEMI assumes no liability and provides no warranty (either expressed or implied) and is not responsible for any damage incurred to your hardware, software, data, or property resulting from usage of the materials or intellectual property except as outlined in the GOWINSEMI Terms and Conditions of Sale. All information in this document should be treated as preliminary. GOWINSEMI may make changes to this document at any time without prior notice. Anyone relying on this documentation should contact GOWINSEMI for the current documentation and errata.

Revision History

Date	Version	Description
02/19/2019	1.0E	Initial version published.
07/18/2019	1.1E	MCU hardware design and software programming design support extended peripherals: CAN, Ethernet, SPI-Flash, RTC, DualTimer, TRNG, I2C, SPI, SD-Card.
08/18/2019	1.2E	<ul style="list-style-type: none">● MCU hardware design and software programming design support extended peripheral: DDR3 Memory;● Known issues of ITCM, DTCM Size and IDE fixed.

Contents

Contents	i
List of Figures	ii
List of Tables	iii
1 Overview	1
2 Hardware Resource	2
3 Software Resource	3
4 Reference Design	4
5 Debugging Flow	5
5.1 Gowin_EMPU_M1 Hardware Design	5
5.1.1 Hardware Design	5
5.1.2 Physical Constraints	5
5.2 Gowin_EMPU_M1 Software Programming	5
5.3 Board Level Connection	5
5.4 Serial Debugging Assistant	6

List of Figures

Figure 5-1 Serial Debugging Assistant Software 6

List of Tables

Table 5-1 UART0/1 Port Constraint 5

1 Overview

Gowin_EMPU_M1 supports serial port debugging. The master computer communicates with the slave computer by serial ports. Serial debugging assistant software is used to trace the debugging information on the PC side.

2Hardware Resource

- Development board: DK-START-GW2A18 V2.0
 - GW2A-LV18PG256C8/I7
- USB to serial port interface board
- PC Computer

3 Software Resource

- GOWIN FPGA Designer version 1.9.x Beta
- ARM Keil MDK or GOWIN MCU Designer
- Serial Debugging Assistant Software

4 Reference Design

- Gowin_EMPU_M1\ref_design\MCU_RefDesign\Keil_RefDesign\uart
- Gowin_EMPU_M1\ref_design\MCU_RefDesign\GNU_RefDesign\cm1_uart

5 Debugging Flow

5.1 Gowin_EMPU_M1 Hardware Design

5.1.1 Hardware Design

1. Select Gowin_EMPU_M1 in Gowin IP Core Generator.
2. Configure Cortex-M1 and APB Bus Peripherals, select UART0 or UART1, and generate Gowin_EMPU_M1 hardware design with UART function.
3. Instantiate Gowin_EMPU_M1, import user designs, and connect ports between user design and Gowin_EMPU_M1,
4. Or use Gowin_EMPU_M1 reference design:
Gowin_EMPU_M1\ref_design\FPGA_RefDesign\Debug_RefDesign or NoDebug_RefDesign

5.1.2 Physical Constraints

Constrain the UART0 and UART1 port in Gowin_EMPU_M1 to FPGA IO.

5.2 Gowin_EMPU_M1 Software Programming

Please refer to
Gowin_EMPU_M1\ref_design\MCU_RefDesign\Keil_RefDesign\uart or
GNU_RefDesign\cm1_uart

5.3 Board Level Connection

Connect DK-START-GW2A18 V2.0 to USB to serial port board using jumper. The UART0 and UART1 port connection in the reference design is as shown in Table 5-1.

Table 5-1 UART0/1 Port Constraint

UART	Ports	IO
UART0	RXD	M14
	TXD	K12
UART1	RXD	J13
	TXD	H13

5.4 Serial Debugging Assistant

Open the serial debugging assistant software, as shown in Figure 5-1.

1. Refer to the PC device manager to select a proper communication port.
2. Refer to the baud rate set in the software programming design to configure the serial port communication baud rate.
3. Open the serial port.
4. Send and receive the debugging information.

Figure 5-1 Serial Debugging Assistant Software



